**HYDRAULIC VALVES** 

SEQUENCE VALVE SQV SERIES Specification Sheet



CROSS

The **CROSS sequence** or **SQV valve** is designed to alternately operate a pair of **agricultural guide marker cylinders** on a row marker system.

## **OPERATION:**

**System diagram and valve layout** represent the main cylinder "C" in retracted position *(imple-ment down)*, with marker cylinder "A" extended *(marker up)*. Marker cylinder "B" is retracted *(marker down)*.


At the end of a row, cylinder "C" is extended to lift the implement pressurizing ports "A" and "B" through the sequence valve spool. Marker cylinder "B" would then extend *(marker up)*. No flow would pass through "A" port since cylinder "A" is already extended. This condition causes a pressure drop between the "A" & "B" port ends of the sequence valve which shifts the spool to the "B" port end.

Starting a new row, main cylinder "C" is retracted *(implement down)* pressurizing marker cylinders "A" and "B" to retract. However, port "B" flow passages are blocked by the spool and integral check in "B" port. Consequently, only marker cylinder "A" is allowed to retract *(marker down)*. Upon completion of this row, main cylinder "C" is again extended, and the marker cylinder "A' is raised. The pressure differential on the spool shifts the spool to the port "A' end preparing marker cylinder "B" to be lowered. Once the implement and "B" port marker are lowered. the guide marker system will have completed its full cycle and be back in its original position.

## Features:


- 2 position, 3 port (3/4-16 SAE)
- M18 x 1.5 threads also available
- Rated to 2500 psi, 2 gpm
- Rugged construction
- 100% testing

## STANDARD INSTALLATION SHOWN WITH IMPLEMENT CYLINDER



**SQV SERIES** 

SEQUENCE VALVE PARTS CROSS



PARTS LIST

0	PART NO.	DESCRIPTION	QTY
1	1 V 1 8 8 0	O-RING BOSS PLUG ASSEMBLY · · · · · ·	2
2	1 V 1 8 8 2	* SPOOL · · · · · · · · · · · · · · · · · ·	1
З	1V2003	* BODY MACHINING ·····	1
4	1 V 2 0 0 1	CHECK VALVE RETAINER	2
5	3V4153-022	O-RING BOSS PLUG ASSEMBLY	· 1
6	2A0017-6	BALL ( <sup>3</sup> /16")	2
7	2A0017-8	BALL ( 1/4") ·····	• 1
8	2A9018-3	CHECK VALVE SPRING	· 2
9	2A9024-1	SPRING	· 1
	2A0353-12	SHIPPING PLUG	3
VALVE E	LECY-FIT HONING PROCESS AT FACTORY, BODY, ELIMINATES THE POSSIBILITY OF OR TE ITEMS		



CROSS MANUFACTURING, INC. 100 James H. Cross Blvd. Lewis, Kansas 67552 Phone 620/324-5525; FAX 620/324-5737; e-mail: info@crossmfg.com